



covered in paint

clear - gloss satin matt

interior/exterior

## Intro

Covered In Paint Clear is a quick dry, low odour water-based clear finish designed for sealing or glazing over finishes. Covered In Paint Clear is specially formulated water-based acrylic polymer system. It provides a tough, non-yellowing coating.

## Location

Covered In Paint Clear is suitable over finishes for such as Verve, Aspriso, Stucco, Stone Inda, Metalescence Fine, Mediterranean Wash, interior timber wall panelling, joinery, doors, furniture, and even Flat Acrylic. It is ideal for use on light coloured timbers such as Pine, Ash, and Western Red Cedar etc. It is also suitable for use on MDF board. Covered In Paint Clear is ideal where a quick drying, low odour clear finish is desirable. If timber is not to be stained, seal with 1 coat of Covered In Paint Clear before filling in nail holes with an Acrylic Timber Putty. **Covered In Paint Clear Gloss/Satin/Matt** is **not** suitable for exterior timber and should **not** be used on extreme wear areas such as floors, bench tops, or surfaces subjected to direct heat.

## Preparation

### New Timber

Ensure the timber is dry, free from dirt, grease or wax. Sand the surface smooth and dust off. Fill nail holes or cracks with Timber Putty in a matching colour. Allow to dry at least 30 minutes, then sand smooth.

### Previously Varnished Surfaces in Poor Condition

If the varnish is badly worn or peeling it must be completely removed by scraping, sanding or by use of paint stripper. Treat stripped timber as new work.

## Preparatory coats

Stir contents thoroughly with a flat stirrer before and during use. Apply 2 or 3 generous coats with a good quality, fine bristled brush. Allow 3hrs between each coat.

### New Timber

Thin the first coat up to 5% with clean water. No thinning is required for subsequent coats.

Apply evenly over the surface, finishing with brush strokes along the grain. When covering large areas, take care to maintain a "wet edge" and do not go back over the clear finished surface once the film has set. Allow a minimum of 3 hours drying before lightly sanding and recoating. Coat windows sparingly in contact areas. To avoid sticking, move windows within 30 minutes.

If applying by roller use a short nap roller 6-10mm and can be thinned with up to 5% water.

## Packaging

Available in 1 litre and 4 litre quantities.

## Contact

For inquiries, please contact *Covered in Paint* on (02) 9519 0204.

clear - gloss satin matt