



## covered in paint

eggshell  
interior

### Intro

Functional, easy to use and sensitive to the environment, the Covered in Paint Acrylic range offers a finish for all interior and exterior elements of a building/home. A washable finish with a proprietary stain guard protection belies the soft flat finish. Those endeavouring to achieve a matt appearance without compromising practicality, **Eggshell Acrylic** has become the choice.

### Quite simply, matt appearance - low sheen performance

In response to the needs of their customers, *Covered in Paint* is addressing the environmental concerns in the design of their paint. With low VOC's, low odour and as a water-based system, **Eggshell Acrylic** makes use of creative technology to minimize the environmental impact in the painting process. The excellent self-levelling properties allow the paint to achieve a very smooth surface finish that offers easy touching-up. In application, **Eggshell Acrylic** is a simple paint with reduced splattering and self-levelling properties to create a smooth matt finish with ease. From gentle off-whites to saturated hues, all colours are achievable.

### Location

Suitable for use on interior surfaces, including timber, masonry, brick, fibre cement, new cement surfaces, paper faced plasterboard, new plaster surfaces, and previously painted surfaces in good condition.

### Preparation

Ensure surface is in sound condition, clean and dry. Fill cracks or holes with suitable filler. Allow to dry and sand smooth, prior to applying sealer undercoat. On glossy surfaces remove gloss with 120-220 grade or finer sanding paper. For previously enamelled surfaces test a small area after sanding for adhesion. If necessary oil based undercoat or Sterling Paints Primer Undercoat may be required.

### Preparatory coats

New Timber and Masonry surfaces Undercoat with one or two coats of Acrylic Primer Undercoat. Apply two coats of **Eggshell Acrylic**. Allow two hours drying between coats, lightly sanding between coats. Brick, Fibre Cement, undercoat with one or two coats of Acrylic Primer Undercoat. Apply two coats of **Eggshell Acrylic**. Paper faced plasterboard spot prime joints and any filled areas, apply one or two coats of Primer Undercoat. Then apply two coats of **Eggshell Acrylic**. Bare Iron, Steel and Galvanised Iron. If the surface is rust-free, apply one or two coats of a Metal Primer. Allow a minimum of 24 hours to dry. Prepare rusted surfaces with appropriate rust treatment prior to painting with metal primer. Allow 24 hours to dry between coats and before applying two coats of **Eggshell Acrylic**. New Plaster surfaces apply one coat of pigmented sealer followed by two coats of **Eggshell Acrylic**. Previously painted water based surfaces. No undercoat or primer required in sound condition - depending on existing colour.

### Colours

Available in all standard and custom colours.

### Packaging

Available in 1 litre, 4 litre and 15 litre quantities.

### Contact

For inquiries, please contact *Covered in Paint* on (02) 9519 0204.